

LEVELING 135

САМОВЫРАВНИВАЮЩИЕСЯ ПЛАТФОРМЫ

ТЕХ. ХАРАКТЕРИСТИКИ

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-4159
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73

Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35

Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

Адрес: <https://orsi.nt-rt.ru> || эл.почта: ois@nt-rt.ru



MACHINE

3 DIFFERENT TYPE OF STEERING

Standard

REAR WHEELS AUTOMATIC CENTERING

Standard

SLIDING PLATFORMS HYDRAULIC OPENING

Standard

PARAPETS TOTALLY OVERTURNABLE

Standard

VERTICAL SCALE

Standard

SLIDING AND HEIGHT ADJUSTABLE GUIDE CONSOLLE

Standard

SPEED MEMORY CONTROLLED BY GUIDE CONSOLLE WITH AUTO PILOT

Standard

LOMBARDINI ENGINE 3 CYL-25 HP

Standard

TIRES 27X10-15,3 TRACTOR

Standard

TIRES WHEELS 10/75-15,3 TRACTOR

Опция

MANUAL LONGITUDINAL LEVELING

Опция

AUTOMATIC LONGITUDINAL LEVELING

Опция

MANUAL CROSS-SECTIONAL LEVELING

Опция

AUTOMATIC CROSS-SECTIONAL LEVELING

Опция

AUTOMATIC LONGITUDINAL AND CROSS-SECTIONAL LEVELING

Опция

PANTOGRAPH ELEVATOR WITH ROLLER GATE (FRONT AND/OR BACK MOUNTED)

Опция

HYDRAULIC TILTING FORKS (FORNT AND/OR BACK MOUNTED)

Опция

COLUMNAR ELEVATOR WITH ROLLER GATE BACK MOUNTED - LOAD KG.800

Опция

COLUMNAR ELEVATOR WITH ROLLER GATE - LOAD KG.500 (FRONT AND/OR BACK MOUNTED)

Опция

ROLLER GATE ELEVATOR WITH INCLINATION - LOAD KG.800

Опция

ADDITIONAL BINS SUPPORT WITH ROLLER GATE MAX.LOAD 150 KG FOR COLUMNAR ELEVATOR - LOAD KG.500

Опция

ADDITIONAL BINS SUPPORT WITH ROLLER GATE MAX LOAD 150 KG FOR COLUMNAR ELEVATOR - LOAD KG.800

Опция

UNDER BELLY PLATFORM'S ROLLER GATES

Опция

UNDER FOOT PLATFORM'S ROLLER GATES

Опция

UNDER BELLY/FOOT PLATFORM'S ROLLER GATES

Опция

STOP BINS ON ROLLER GATES (4 PIECES)

Опция

FRONT AND REAR LIGHTS SYSTEM FOR GREATER VISIBILITY AT WORK

Опция

COMPRESSOR SET 550 LT (5 QUICK COUPLING AIR PLUGS) - SINGLE AIR TANK

Опция

TROCKNER

Опция

ENGINE RETURNS TO IDLE WHEN MACHINES STOPS

Опция

AUTOMATIC MOVING FORWARD DRIVE WITH DOUBLE ULTRASOUNDS SENSOR

Опция

AUTOMATIC TELESCOPIC-MANUAL MOVING FORWARD DRIVE

Опция

AUTOMATIC TELESCOPIC- HYDRAULIC MOVING FORWARD DRIVE

Опция

HYDRAULIC BRAKES ON REAR WHEELS

Опция

AUTO PILOT: BACK CONTROL STOP & GO (ONLY ON FRUIT HARVESTER WITH AUTOMATIC FORWARD DRIVE) (SPEED MEMORY CONTROLLED ALSO ON BACK OF FRUIT HARVESTER)

Опция

TRACER OVERHEAD OBSTACLES (BLOCK RACING)

Опция

TIRES WHEELS 31X15.5-15 TRACTOR

Опция

TIRES WHEELS LOW PRESSURE BKT 320/65 R16

Опция

ITALIAN ROAD APPROVAL - ONLY FOR THE ITALIAN MARKET

Опция

TOWING KIT (INCLUDES DRAWBAR, BAR LIGHT, LICENSE PLATE, REFLECTORS, FOOT LIFT, MANUAL RELEASE OF BACK WHEELS)

Опция

WHEELS RAISED CYLINDER KIT (IN PLACE OF THE LIFTING FOOT)

Опция

KIT COUPLE FORKS

Опция

KUBOTA ENGINE 3 CYL – 29,5 HP

Опция

KUBOTA ENGINE 3 CYL – 18,5 KW - 25 HP USA VERSION TIER 4

Опция

ELEVATOR CONTROL FROM GROUND (BACK MOUNTED)

Опция

ELEVATOR CONTROL FROM PLATFORM (BACK MOUNTED)

Опция

ELEVATOR INCLINATION CONTROL FROM PLATFORM (BACK MOUNTED)

Опция

RADIO

Опция

TENDS (NO WITH LONGITUDINAL LEVELING)

Опция

CRATE HOLDER

Опция

FRUIT HOLDER BOX

Опция

QUICK UNCOUPLING ROLLER GATE (ONLY WITH UNDER BELLY OR UNDER BELLY/FOOT ROLLER GATES)

Опция

REAR EMERGENCY STOP BY PLATFORM

Опция

EXTENSION PLATFORM FOR COLUMNAR ELEVATOR LOAD 800 KG PLATFORM LOAD : 350 KG ON THE CENTRAL STAGE AND 100 KG ON EACH EXTENSION PLATFORM

Опция

TRANSMISSION

4 DRIVE WHEELS

Standard

4 STEERING WHEELS

Standard

HYDROSTATIC TRANSMISSION

Standard

ELECTRO-IMPLEMENTED GEARBOX 2 SPEEDS

Standard

WORKING SPEED (MARCH I[^])0,7 M/SEC

Standard

SPEED OF MOVING (MARCH II[^])0-10 KM/H

Standard

NEGATIVE PARKING BRAKE OPERATED BY INDIPENDENT PUMP

Standard

DIFFERENTIAL SELF-LOCKING

Опция

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73

Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35

Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

Адрес: <https://orsi.nt-rt.ru> || эл.почта: ois@nt-rt.ru