

ML PLUS 28 32 36

ОТВАЛЫ ДЛЯ СНЕГА

ТЕХ. ХАРАКТЕРИСТИКИ

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-4159
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73

Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35

Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

Адрес: <https://orsi.nt-rt.ru> || эл.почта: ois@nt-rt.ru

ML PLUS

SNOW BLADE

ML PLUS	28	32	36
MACHINE			
Signal flags	✓	✓	✓
Blade micro alloyed steel made high yield STRENGTH 700/S700MC	✓	✓	✓
Change angle of incidence that allows the installation of different types of scraping blades	✓	✓	✓
Swing side	✓	✓	✓
Curved lift kit	✓	✓	✓
Straight lift kit	•	•	•
Rubber splash guard	•	•	•
Set of LED clearance lights with supports	•	•	•
French signalling kit	•	•	•
German signalling kit in presence of clearance lights	•	•	•
Set of auxiliary lights completed with galvanized support and direction indicators 12V - 24V	•	•	•
Polyurethane lateral edges	•	•	•
Forced release to improve the capacity of scraper	•	•	•
ATTACHMENT FOR TRACTOR			
Attachment 3 points Cat. II	✓	✓	✓
DIN 76060 plate size 3 ("B") with parallelogram lifting	•	•	•
DIN 76060 plate size 5 ("A") with parallelogram lifting	•	•	•
SETRA plate with parallelogram lifting	•	•	•
TERNA hook plate version with fake piston to couple to arms GROUP 3	•	•	•
TERNA hook plate version with fake piston to couple to arms GROUP 5	•	•	•
DIN 76060 Plate Size 3/ ASSALONI mt 1.20	•	•	•
HYDRAULIC SYSTEM			
Hydraulic control right-left rotation with by pass safety valve	✓	✓	✓
Kit accumulator weight (not compatible with the basic version with 3-point attachment) (necessary with Bi-steel system for insertion 2nd steel or polyurethane knife)	•	•	•
Electro-hydraulic unit EP5-H complete panel with control box in the cab socket + plug wire and electrical cable: 12 V - 24 V	•	•	•
Electro-hydraulic unit EP7-H (for implement with option bi-steel rubber knife) complete panel with control box in the cab socket + plug wire and electrical cables 24 V	•	•	•
SAFETIES			
Side bumpers	✓	✓	✓
Side bumpers	✓	✓	✓
N° Sectors	1	1	1
Kit pair of auxiliary springs to increase resistance to release	•	•	✓
SCRAPING KNIVES			
HARDOX HB400 steel knives	✓	✓	✓
Scraping polietilene HD (plastic) knife replacing the steel one	•	•	•
Scraping rubber knife replacing the steel one	•	•	•
Scraping polyurethane knife replacing the steel one	•	•	•
Bi-steel system for insertion 2nd steel or polyurethane knife (it is necessary to add the weight accumulator kit)	•	•	•



✓

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73

Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35

Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

Адрес: <https://orsi.nt-rt.ru> || эл.почта: ois@nt-rt.ru